# Safety Modules Safety Mat and Safety Edge modules Types NST02C, NSE02C





- Performance Level d (safety category 3) according to EN ISO 13849-1
- 2 x 5 A NO safety outputs
- Automatic / manual or monitored manual reset
- Four (NST02C) or two (NSE02C) wire inputs
- LED indication for outputs status and power supply ON
- Connection by fixed screw terminals
- For mounting on DIN-rail in accordance with DIN/EN 50 022
- 22.5 mm Euronorm housing

#### **Product Description**

Safety Mat (NST02C) and Safety Edge (NSE02C) modules according to EN ISO 13849-1. These products are the control unit of the safety system for dangerous areas monitoring

and they are designed to be used with the Carlo Gavazzi SM safety mat and SE safety edge.

Both automatic/manual or monitored manual restart versions are available.

# Ordering Key N ST 0 2 C B24 S A Housing Function Auxiliary outputs Safety outputs Safety category Power supply Terminals Start/Reset type

#### **Type Selection**

Safety outputs	Performance Level/ Safety Category	Application	Start/Reset type	Supply: 24 VAC/DC
2 NO	d/3	Safety Mat	Automatic / Manual	N ST 0 2 C B24 S A
2 NO	d/3	Safety Mat	Monitored manual	N ST 0 2 C B24 S C
2 NO	d/3	Safety Edge	Automatic / Manual	N SE 0 2 C B24 S A
2 NO	d/3	Safety Edge	Monitored manual	N SE 0 2 C B24 S C

## **Time Specifications**

Delay ON energisation	≤ 30 ms			
Delay ON de-energisation	≤ 30 ms			
Recovery time				
Nxx02CB24SA	$2 s \pm 20\%$			
Nxx02CB24SC	400 ms ± 20%			

# **Input Specifications**

Function	4 wires (NST) 2 wires (NSE)
External resistor to be connected between the two layers (NSE02C)	8.2 kΩ
Input current NST02C Terminals T11-T12 Terminals T21-S22 Terminals S1-S2 NSE02C Terminals T11-T22 Terminals S1-S2	Max. 2 mA Max. 2 mA Max. 4 mA Max. 2 mA Max. 4 mA

#### **Output Specifications**

Safety outputs	Performance Level d (Safety category 3) (EN ISO 13849-1) 2 NO (13-14, 23-24)
Rated insulation voltage	250 VAC (rms)
Contact ratings (AgSnO <sub>2</sub> ) Resistive loads AC1 DC12 Small inductive loads AC15	07.02.120
DC13	1.2 A @ 24 VDC
External contact fuse protection	5 A fast, 4 A slow
Mechanical life	> 10 <sup>7</sup> operations
Electrical life	> 10 <sup>5</sup> operations
<b>Dielectric strength</b> Dielectric voltage	2.5 kVAC (rms)



#### **Supply Specifications**

Power supply Rated operational voltage through terminals:	Overvoltage cat. III (EN IEC 60664)	
A1, A2	24 VAC ±15%, 45 to 65 Hz 24 VDC ±15%	
Short circuit protection	Internal PTC	
Dielectric voltage		
Supply to input	None	
Supply to output	4 kV (1.2/50 μs)	
Input to output	4 kV (1.2/50 μs)	
Rated operational power	Max. 5 VA	

## **General Specifications**

Indication for Power supply ON Output relays ON	LED, green LED, green (CH1, CH2)	
Environment Degree of protection Pollution degree Operating temperature Storage temperature	(EN IEC 60529) IP 20 2 0 to 55°C, R.H. < 95% -30 to 65°C, R.H. < 95%	
Housing dimensions	22.5 x 84 x 100 mm	
Weight	Approx. 200 g	
Screw terminals Tightening torque Approvals	Max. 0.5 Nm	
CE Marking	Yes	
EMC Immunity Emission	Electromagnetic Compatibillity Acc. to EN IEC 61000-6-2 Acc. to EN IEC 61000-6-3	

#### **Mode of Operation**

The safety modules NST02C and NSE02C monitor the status and the integrity of Safety Mats and Safety Edge respectively, according to 2006/42/EC Machinery Directive.

If the unit is correctly supplied and the safety mat (or edge) is not pressed, the module is enabled to close the safety outputs and the external contactors can be energized.

When the safety mat (edge) is pressed the module opens the safety outputs and the external contactors can not be energized.

#### **Automatic START**

Provided that the terminals S1 and S2 are connected and the safety mat (edge) is not pressed, the module closes its own safety outputs.

The relevant CH1 and CH2 LED turn on.

If the safety mat (edge) is pressed (layers in contact to each other), the module immediately forces the safety outputs to open.

After the releasing of the safety mat (edge), a new operating cycle starts when a time of 2 seconds has expired.

#### **Manual START**

Provided that the mat (edge) is not pressed, the safety outputs close as soon as the START pushbutton is pushed (connecting S1 and S2).

The relevant CH1 and CH2 LED turn on.

A new operating cycle is possible only after mat (edge) releasing, pushing the START button and waiting for a time of 2 seconds.

#### **Monitored manual START**


The monitored manual START versions (NST...C and NSE...C) work as described in the previous paragraph (Manual START) except for a minimum delay of 400 ms from the mat (edge) releasing to the pushing of the START button.


If the mat (edge) is released with the START switch already closed, the safety outputs do not close: it is necessary to release the START button and the safety mat (edge) before starting a new cycle, then (after at least 400 ms) operate again the START button.


It means that if the START button gets welded, the outputs do not close anymore.



## **Operation Diagrams**











# **Wiring Diagrams**





#### **Dimensions**

